

CirrusSense™ TDWLB-G2 Battery Replacement.



DESCRIPTION

When replacing your TDWLB-G2 battery, please follow the important procedures listed below:

1. Remove the Cap by turning it counter clockwise (see below photo)
2. Place a small screw driver blade between plug and socket and pry up to remove plug from socket. Plug only fits one way. Remove battery.
3. Wait a minimum of 90 seconds before inserting the new battery. The transducer needs to reset before connecting new battery.
4. If your sensor includes a temperature probe, BEFORE replacing battery, ensure the temp probe is connected to the M5 connector PRIOR TO connecting the battery.
5. Replace old Cap O'ring with new one supplied.
6. Replace cap turning it clockwise until it stops, lining up the arrows.



To Remove Cap

